



ECR KEY+PB+LAMP
Components will be installed on ECR console
4 22mm hole need to be drilled on the console to install these parts

Use a 4-core cable connect to the main circuit

ER ENTRANCE KEY+PB+LAMP
Components in a metal box

Use a 4-core cable connect to the main circuit

- OPERATION:**
1. Power supply: DC24V, Always ON
 2. To activate the system, turn the key switch and hold for 1 seconds
 3. To deactivate system, tuen the key switch and hold for 3 seconds
 4. Press RESET push button to reset dead man alarm when the horn sounds and button light filcks within 3 minutes

R=4.7K 1W
C=100uF/50V 105C